



ZEPHYR LOCK

Innovative locking solutions for the locker industry

30 Pecks Lane
Newtown, CT 06470
Toll Free: 866-937-4971
Fax: 203-778-1016
Email: info@zephyrlock.com
Web: www.zephyrlock.com

How to Operate Model 2254/2255 RFID Electronic Lock

Shared Use Mode

To Close:

- 1.) Select any available/open locker. Red light will flash for lockers already in use
- 2.) Press "ZEPHYR" button
- 3.) Enter self-selected 4 digit passcode
- 4.) Press "ZEPHYR" button

To Open:

- 1.) Press "ZEPHYR" button
- 2.) Enter your self selected 4 digit passcode
- 3.) Press "ZEPHYR" button

*The bolt stays open and the previous passcode is erased

*Open & Close by RF Card Key: Press "ZEPHYR" button and touch the Control Card or User Card to the lock face.



Permanent Use Mode

*Locks are shipped to accept default code 1-2-3-4 until Permanent passcode is set by user

Once lock is mounted, use the default code to lock the door:

- 1.) Press "ZEPHYR" button
- 2.) Press 1-2-3-4
- 3.) Press "ZEPHYR" button again

To change Passcode:

- 1.) Press "ZEPHYR" button
- 2.) Enter old 4 digit passcode (if programming lock for the first time, this will be 1-2-3-4)
- 3.) Press "ZEPHYR" button
- 4.) While lock is open, enter in new 4 digit passcode
- 5.) Press "ZEPHYR" button
- 6.) Enter new 4 digit passcode
- 7.) Press "ZEPHYR" button

Open & Close by Passcode:

- 1.) Press "ZEPHYR" button
- 2.) Enter in your 4 digit passcode
- 3.) Press "ZEPHYR" button again

*To Close – Lock bolt automatically re-engages after several seconds